

# WIFI ENABLED DEVICES

# INTERNET CONNECTION SETUP GUIDE - WIFI PROTECTED SETUP (WPS)

Look on your WiFi router for a button with the rotating arrows symbol pictured below. If you have this button, you can use this setup method. If not, use WEB BASED METHOD. WPS is available on most recently purchased popular brand routers.




## 1. PRESS THE 49 BUTTON ON YOUR ROUTER

Generally, you will have at least 2 minutes to enable WPS on your device once you press this button. Refer to your router owners manual for more information on WPS if needed.

#### 2. ENABLE WPS ON YOUR DEVICE


To enable WPS on your device, press and hold the MANUAL ON/OFF button for 15 seconds.



While holding the button the light will turn off after 5 seconds, then 10 seconds later it will turn back on again. When it does, release the button. The light will begin to flash indicating WPS mode is enabled. If the light blinks for less than 2 minutes, connection was successful. If blinking continues for 2 full minutes, perform WEB BASED METHOD for setup.

# REGISTER ON THE WEB MANAGEMENT PORTAL

- 1. Go to www.lockstateconnect.com and register for an account.
- 2. Click Sign Up to begin the registration process and follow all steps.
- 3. Once registered, you can turn your device on and off remotely, set schedules for your device and more.



### INTERNET CONNECTION SETUP GUIDE - WEB BASED METHOD

#### 1. SEARCH FOR DEVICE NETWORK

If WPS is not available on your router, your device produces a WiFi signal that you can connect with. Once connected, you can then point your device to your WiFi router.

To connect to the device, you can use either a laptop computer or smartphone. Search for the available wireless networks to find the device signal.

#### From a Cell Phone:

In your phone settings, select WiFi to view networks.



#### From a PC:

In your system tray, select network center icon.



#### 2. CONNECT TO DEVICE NETWORK


From the list of available wireless networks, select the network starting with "CB xxxxxx". (You will have your own unique 6-digit number instead of "xxxxxx")




After selecting this network, you will be prompted for the password. Enter the WiFi Key you noted previously and join the network. Your computer or phone is now connected to the device.

#### 3. CONNECT DEVICE TO YOUR WIFI ROUTER


1. Open your phone or PC web browser (as if going to a website). Go to "10.10.1.1" in address bar.



2. After the device searches for available networks, select your WiFi router and click "Next".



3. Enter your router's password and then click "Submit".



You should hear your device "beep". Your device is connected.



#### REGISTER ON THE WEB MANAGEMENT PORTAL

- 1. Go to **www.lockstateconnect.com** and register for an account.
- 2. Click Sign Up to begin registration process and follow all steps.
- Once registered, you can turn your device on and off remotely, set schedules for your device and more.

This product includes local control of key functions. For remote access, alerts, linking to other Cloudbeam enabled products or other premium services there is a \$1.00/month (\$12.00/year) service fee.



**Questions, problems, missing parts?** Before returning to your retailer, call our customer service department at (877) 254-5625, 8 a.m. - 5 p.m., CST, Monday - Friday.